

Operating Manual

**alpha Value Line
NP / NPL**



Revision history

Revision	Date	Comment	Chapter
01	04.08.2014	new version	all
02	05.10.2015	Renamed as NP; NPA	all
03	22.10.2015	NPA removed; NPL inserted	1, 3, 5, 9

Service

In case you have technical questions,
please contact:

WITTENSTEIN alpha GmbH

Customer Service
Walter-Wittenstein-Straße 1
D-97999 Igersheim

Tel.: +49 7931 493-12900

Fax: +49 7931 493-10903

E-mail: service-alpha@wittenstein.de

© WITTENSTEIN alpha GmbH 2015

This documentation is copyright protected.

WITTENSTEIN alpha GmbH reserves all the rights to photo-mechanical reproduction, copying, and the distribution by special processes (such as computers, file media, data networks), even in parts.

Subject to technical and content changes without notice.

Contents

1	Regarding this manual.....	2
1.1	Signal words	2
1.2	Safety symbols.....	2
1.3	Design of the safety instructions	3
1.4	Information symbols.....	3
2	Safety.....	4
2.1	EC directives	4
2.1.1	Machinery directive	4
2.1.2	RoHS.....	4
2.2	Dangers	4
2.3	Personnel.....	4
2.4	Intended use	4
2.5	Reasonably predictable misuse	4
2.6	Guarantee and liability	5
2.7	General safety instructions	5
3	Description of the gearhead.....	7
3.1	Overview of the gearhead components	7
3.2	Identification plate	7
3.3	Performance statistics.....	8
3.4	Weight.....	8
3.5	Noise emission.....	8
4	Transport and storage	9
4.1	Scope of delivery	9
4.2	Packaging	9
4.3	Transport.....	9
4.4	Storage	9
5	Assembly	10
5.1	Preparations.....	10
5.2	Mounting the motor onto the gearhead	10
5.3	Components mounted onto the output side	12
5.4	Mounting the gearhead to a machine	12
6	Startup and operation	13
7	Maintenance and disposal.....	14
7.1	Maintenance work.....	14
7.1.1	Visual inspection	14
7.1.2	Checking the tightening torques.....	14
7.2	Startup after maintenance work	14
7.3	Maintenance schedule	14
7.4	Notes on the lubricant used	15
7.5	Disposal	15
8	Malfunctions	16
9	Appendix	17
9.1	Specifications for mounting onto a motor.....	17
9.2	Specifications for mounting onto a machine	17
9.3	Tightening torques for common thread sizes in general mechanical engineering	17

1 Regarding this manual

These instructions contain necessary information for the safe operation of the NP / NPL planetary gearhead, referred to as gearhead in the following.

If this manual is supplied with an amendment (e.g. for special applications), then the information in the amendment is valid. Contradictory specifications in this manual thereby become obsolete.

The operator must ensure that these instructions are read through by all persons assigned to install, operate, or maintain the gearhead, and that they fully comprehend them.

Store these instructions within reach of the gearhead.

These **safety instructions** should be shared with colleagues working in the vicinity of the device to ensure individual safety.

The original instructions were prepared in German; all other language versions are translations of these instructions.

1.1 Signal words

The following signal words are used to bring your attention to dangers, prohibitions, and important information:

	<div data-bbox="598 790 877 840">⚠ DANGER</div> <div data-bbox="379 853 1359 925">This signal word points to an imminent danger that can cause serious injuries and even death.</div>
	<div data-bbox="598 960 898 1010">⚠ WARNING</div> <div data-bbox="379 1023 1359 1095">This signal word points to a possible danger that can cause serious injuries and even death.</div>
	<div data-bbox="598 1131 884 1180">⚠ CAUTION</div> <div data-bbox="379 1193 1359 1265">This signal word points to a possible danger that can cause slight to serious injuries.</div>
	<div data-bbox="660 1301 852 1350">NOTICE</div> <div data-bbox="379 1364 1359 1435">This signal word points to a possible danger that can cause material damage.</div>
	<div data-bbox="379 1471 1359 1543">A note without signal word draws your attention to application tips or especially important information when handling the gearhead.</div>

1.2 Safety symbols

The following safety symbols are used to bring your attention to dangers, prohibitions, and important information:



General danger



Hot surface



Suspended loads



Danger of being pulled in




Environment protection



Information

1.3 Design of the safety instructions

The safety instructions of these instructions are designed according to the following pattern:



A = Safety symbol (see Chapter 1.2 "Safety symbols")

B = Signal word (see Chapter 1.1 "Signal words")

C = Type and consequence of the danger

D = Prevention of the danger

1.4 Information symbols

The following information symbols are used:

- Indicates an action to be performed
- ➡ Indicates the results of an action
- ⓘ Provides additional information on handling

2 Safety

These instructions, especially the safety instructions and the rules and regulations valid for the operating site, must be observed by all persons working with the gearhead.

In addition to the safety instructions in this manual, also observe any (legal and otherwise) applicable environmental and accident prevention rules and regulations (e.g. personal safety equipment).

2.1 EC directives

2.1.1 Machinery directive

The gearhead is considered a "machine component" and is therefore not subject to the EC Machinery Directive 2006/42/EC.

Operation is prohibited within the area of validity of the EC directive until it has been determined that the machine in which this gearhead is installed corresponds to the regulations within this directive.

2.1.2 RoHS

The homogeneous materials used in the gearhead fall below the amounts of hazardous materials limited by directive 2011/65/EU Annex II.

- Lead (0.1%)
- Mercury (0.1%)
- Cadmium (0.01%)
- Hexavalent chromium (0.1%)
- Polybrominated biphenyls (PBB) (0.1%)
- Polybrominated diphenyl ether (PBDE) (0.1%)

Installation of the gearhead therefore has no effect on the restriction of using certain hazardous materials in electrical and electronic equipment as required in the directive.

2.2 Dangers

The gearhead has been constructed according to current technological standards and accepted safety regulations.

To avoid danger to the operator or damage to the machine, the gearhead may be put to use only for its intended usage (see chapter 2.4 "Intended use") and in a technically flawless and safe state.

- Read the general safety instructions before beginning work (see Chapter 2.7 "General safety instructions").

2.3 Personnel

Only persons who have read and understood these instructions may carry out work on the gearhead.

2.4 Intended use

The gearhead serves to convert torques and speeds. It is suitable for all industrial applications.

The gearhead may not be operated in areas with explosion hazards. In food processing, the gearhead may be used only next to or under the foodstuff area.

The gearhead is intended for installation on motors that:

- Correspond to the design B5 (in the event of deviations, consult our Customer Service department [technical Customer Service department]).
- Have a radial and axial runout tolerance according to DIN EN 50347.
- Have a cylindrical shaft end with tolerance class h6 to k6.

2.5 Reasonably predictable misuse





Any usage that exceeds the maximum permitted speeds, torques and temperature is considered a misuse and is therefore prohibited.





2.6 Guarantee and liability

Guarantee and liability claims are excluded for personal injury and material damage in case of

- Ignoring the information on transport and storage
- Improper use (misuse)
- Improper or neglected maintenance and repair
- Improper assembly / disassembly or improper operation (e.g. test run without secure attachment)
- Operation of the gearhead when safety devices and equipment are defective
- Operation of the gearhead without lubricant
- Operation of a heavily soiled gearhead
- Modifications or reconstructions that have been carried out without the approval of **WITTENSTEIN alpha GmbH**

2.7 General safety instructions

	<div style="background-color: #FFD700; text-align: center; padding: 5px;">⚠ WARNING</div> <p>Objects flung out by rotating components can cause serious injuries.</p> <ul style="list-style-type: none"> Remove objects and tools from the gearhead before putting it into operation. Remove/Secure the shaft key (if available) if the gearhead is operated without attachments on the output/drive side.
	<div style="background-color: #FFD700; text-align: center; padding: 5px;">⚠ WARNING</div> <p>Rotating components on the gearhead can pull in parts of the body and cause serious injuries and even death.</p> <ul style="list-style-type: none"> Keep a sufficient distance to rotating machinery while the gearhead is running. Secure the machine against restarting and unintentional movements during assembly and maintenance work (e.g. uncontrolled lowering of lifting axes).
	<div style="background-color: #FFD700; text-align: center; padding: 5px;">⚠ WARNING</div> <p>A damaged gearhead can cause accidents and injury.</p> <ul style="list-style-type: none"> Never use a gearhead that has been overloaded to due misuse or a machine crash (see chapter 2.5 "Reasonably predictable misuse"). Replace the affected gearhead, even if no external damage is visible.
	<div style="background-color: #FFD700; text-align: center; padding: 5px;">⚠ CAUTION</div> <p>Hot gearhead housing can cause serious burns.</p> <ul style="list-style-type: none"> Touch the gearhead housing only when wearing protective gloves or after the gearhead has been at standstill for some time.

	NOTICE Loose or overloaded screw connections can damage the gearhead. <ul style="list-style-type: none">• Use a calibrated torque wrench to tighten and check all screw connections for which a tightening torque has been specified.
	⚠ WARNING Lubricants are flammable. <ul style="list-style-type: none">• Do not spray with water to extinguish.• Suitable extinguishing agents are powder, foam, water mist, and carbon dioxide.• Observe the safety instructions of the lubricant manufacturer (see Chapter 7.4 "Notes on the lubricant used").
	⚠ CAUTION Solvents and lubricants can cause skin irritations. <ul style="list-style-type: none">• Avoid direct skin contact.
	Solvents and lubricants can pollute soil and water. <ul style="list-style-type: none">• Use and dispose of cleaning solvents and lubricants properly.

3 Description of the gearhead



The gearhead is a single or multistage planetary gearhead which is manufactured in the version "M" (motor-mounted) by default. The output shaft bearing is realized in such a manner that it can accommodate extensive tilting moments and axial forces.

For applications with special safety requirements (e.g. vertical axes, distorted gear inputs) we recommend employing exclusively our products **alpheno[®]**, **RP⁺**, **SP⁺**, **TP⁺**, **TP⁺ HIGH TORQUE** or consulting with **WITTENSTEIN alpha GmbH**.

The motor is centered using the clamping hub and not with the adapter plate. A radial distortion of the motor is avoided.

Various types of motors can be accommodated using an adapter plate and, where necessary, a bushing.


3.1 Overview of the gearhead components

NP / NPL gearhead components		
	A	Gearhead housing
	B	Output shaft
	C	Adapter plate
	D	Threaded bores (see Chapter 5.4 "Mounting the gearhead to a machine")
		

Tbl-1: Overview of the gearhead components

3.2 Identification plate

The identification plate is attached to the gearhead housing.

Designation		
	A	Gearhead type (e.g. NP / NPL) Gearhead size (e.g. 035)
	B	Ratio
	C	Serial number
	D	Lubricant information
	E	Production date
	F	Article code
	G _{1,2}	Material number (option)
	H	Data matrix code (optional) For opening the Internet service platform

Tbl-2: Identification plate (sample values)

3.3 Performance statistics

For the maximum permitted speeds and forces, refer to the respective customer-specific performance data (2093–D...).

For additional information, please contact **WITTENSTEIN alpha GmbH**. Always provide the serial number in this case.

3.4 Weight

The table "Tbl-3" specifies the gearhead weights with a medium-sized adapter plate. If a different adapter plate is mounted, the actual weight can deviate by up to 30 %.

NP gearhead size	005	015	025	035	045
1–stage [kg]	0.7	1.9	3.8	9.4	18.9
2–stage [kg]	0.9	1.9	4.1	9.8	19.5
NPL gearhead size	–	015	025	035	045
1–stage [kg]	-	2.0	4.1	10.0	19.7
2–stage [kg]	-	2.1	4.4	10.4	20.2

Tbl-3: Weight

3.5 Noise emission

For the continuous noise pressure level, see the respective customer-specific performance data (2093–D...).

- Observe the total noise pressure level of the machine.

For additional information, please contact **WITTENSTEIN alpha GmbH**. Always provide the serial number in this case.

4 Transport and storage

4.1 Scope of delivery



- Check the completeness of the delivery against the delivery note.
 - ① Immediately notify the carrier, the insurance company, or **WITTENSTEIN alpha GmbH** in writing of any missing parts or damage.

4.2 Packaging

The gearhead is delivered packed in foil and cardboard boxes.

- Dispose of the packaging materials at recycling sites intended for that. Observe the locally valid regulations for disposals.

4.3 Transport

	<p style="text-align: center;">⚠ WARNING</p> <p>Suspended loads can fall and can cause serious injuries and even death.</p> <ul style="list-style-type: none"> • Do not stand under suspended loads. • Secure the gearhead before transport with suitable fasteners (e.g. belts).
	<p style="text-align: center;">NOTICE</p> <p>Hard knocks, because of falling or hard dropping, can damage the gearhead.</p> <ul style="list-style-type: none"> • Only use hoisting equipment and transports with sufficient capacity. • The maximum permitted lift capacity of a hoist may not be exceeded. • Lower the gearhead slowly.

No special transport mode is prescribed for transporting the gearhead.

Specifications on the weights, refer to Chapter 3.4 "Weight".

4.4 Storage

Store the gearhead in horizontal position and dry surroundings at a temperature of 0 °C to +40 °C in the original packaging. Store the gearhead for a maximum of 2 years. Consult our Customer Service department if the conditions are different.

For storage logistics, we recommend the "first in –first out" method.

5 Assembly


- Read the general safety instructions before beginning work (see Chapter 2.7 "General safety instructions").

The gearhead can be used in any mounting position.

- ① For applications with special safety requirements (e.g. vertical axes, distorted gear inputs) we recommend employing exclusively our products alpheno[®], RP⁺, SP⁺, TP⁺, TP⁺ HIGH TORQUE or consulting with **WITTENSTEIN alpha GmbH**.

5.1 Preparations

The bolts for mounting are not included in the scope of delivery and need to be provided by the customer. Information can be found in the individual assembly steps.

	<p style="text-align: center;">NOTICE</p> <p>Pressurized air can damage the gearhead seals.</p> <ul style="list-style-type: none"> • Do not use pressurized air to clean the gearhead.
---	---


- Clean/De-grease the following components with a clean and lint-free cloth and grease-dissolving, non-aggressive detergent:
 - all fitting surfaces to neighboring components
 - centering
 - the motor shaft
 - the inside diameter of the clamping hub
 - the bushing inside and out
- Check the fitting surfaces additionally for damage and impurities.


5.2 Mounting the motor onto the gearhead

The standard delivery of a gearhead does not include a motor. The motor to be mounted has to:

- correspond to the B5 design
- have a radial and axial runout tolerance according to DIN EN 50347
- and if possible, have a smooth shaft.


- ① If a motor is included in the scope of delivery, then it is already firmly mounted (no assembly necessary).

	<ul style="list-style-type: none"> • Observe the specifications and safety instructions of the motor manufacturer. • Observe the safety and processing instructions for the threadlocker to be used.
---	--




The tightening torque value (C_1) of the clamping bolt (H) can be found on the clamping hub (C).

- ① The value for the tightening torque can also be found in section 9.1 "Specifications for mounting onto a motor", table "Tbl-10".




- Ensure that the motor is mounted if possible in a vertical direction.
- If the motor shaft has a shaft key, remove the shaft key.
 - ① If recommended by the motor manufacturer, insert a half wedge.
- Remove the stopper plug (A) from the mounting bore in the adapter plate (B).
- Turn the clamping hub (C) until the clamping bolt (H) can be reached by the mounting bore.
- Loosen the clamping bolt (H) of the clamping hub (C) by one revolution.
- Push the motor shaft into the clamping hub of the gearhead (E).
 - ① The motor shaft should slip in easily. If this is not the case, the clamping bolt needs to be loosened some more.
 - ① A slotted bushing has to be additionally installed for certain motor shaft diameters and applications.
 - ① The slot of the bushing (if present) and clamping hub have to be flush with the groove (if present) of the motor shaft, see Table "Tbl-4".
 - ① No gap is permitted between motor (D) and the adapter plate (B).

		Designation
	H	Clamping bolt
	I	Clamping ring [part of the clamping hub (C)]
	J	Bushing
	K	Keyed motor shaft
	L	Smooth motor shaft

Tbl-4: Arrangement of motor shaft, clamping hub, and bushing

- ① Motor centering of the motor-mounted gearhead is performed by the clamping hub.
- Smear threadlocker (for example Loctite 243) onto the four bolts (F).
- Fasten the motor (D) onto the adapter plate (B) with the four screws (F).
- Tighten the clamping bolt (H) of the clamping hub (C).
 - ① The value for the tightening torque can also be found in section 9.1 "Specifications for mounting onto a motor", table "Tbl-10".
- Press the enclosed stopper plugs (A) into the mounting bore of the adapter plate (B).


5.3 Components mounted onto the output side

	NOTICE				
	<p>Clamping forces during assembly can damage the gearhead.</p> <ul style="list-style-type: none"> Do not use force when mounting gearwheels and toothed belt pulleys onto the output shaft. Never attempt to assemble by force or hammering! Only use suitable tools and devices for assembly. Make sure not to exceed the maximum permissible static axial forces on the output bearing (see Table "Tbl-5") when pulling or shrink-fitting a gear onto the output shaft. 				

NP size	005	015	025	035	045
$F_{a \max} [N]$	1800	4300	5100	11300	18500
NPL size	–	015	025	035	045
$F_{a \max} [N]$	–	9250	10750	18500	31250

Tbl-5: Maximum permissible static axial forces at static load rating (s_0) = 1.8 and radial force (F_r) = 0

5.4 Mounting the gearhead to a machine




The NP gearhead housing has four threaded bores (A) for bolting the gearhead to a machine.

The NPL gearhead housing has eight threaded bores (A) for bolting the gearhead to a machine.

- Thoroughly clean the output shaft, centering, and fitting surface.

The bolts need to be provided by the customer. The prescribed screw sizes and tightening torques can be found in Chapter 9.2 "Specifications for mounting onto a machine", Table "Tbl-11".



- Smear the bolts with a threadlocker (e.g. Loctite 243).
- Fasten the gearhead on the machine with the fastening screws through the threaded bores.

① Mount the gearhead in such a way that the identification plate remains legible.

① Do not use washers (e.g. plain washers, tooth lock washers).

6 Startup and operation

- Read the general safety instructions before beginning work (see Chapter 2.7 "General safety instructions").

	<p>Improper use can cause damage to the gearhead.</p> <ul style="list-style-type: none">• Make sure that<ul style="list-style-type: none">- the ambient temperature does not drop below -15 °C or exceed $+40\text{ °C}$ and- the operating temperature does not exceed $+90\text{ °C}$.• Avoid icing, which can damage the seals.• For other conditions of use, consult our Customer Service department.• Only use the gearhead only up to its maximum limit values, see Chapter 3.3 "Performance statistics".• Only use the gearhead only in a clean, dust-free and dry environment.
--	--

7 Maintenance and disposal

- Read the general safety instructions before beginning work (see Chapter 2.7 "General safety instructions").

7.1 Maintenance work

7.1.1 Visual inspection

- Check the entire gearhead for exterior damage.
- The sealings are subject to wear. Therefore also check the gearhead for leakage during each visual inspection.
 - ① Check the mounting position, so that no foreign medium (e.g. oil) has collected on the output shaft.

7.1.2 Checking the tightening torques

- Check the tightening torque of the clamping bolt on the motor mounting. If you discover while checking the tightening torque that the clamping bolt can be turned further, tighten it with the prescribed tightening torque.
 - ① The prescribed tightening torques can be found in Chapter 9.1 "Specifications for mounting onto a motor", table "Tbl-10".
- Check the tightening torque of the fastening screws on the gearhead housing. If you discover while checking the tightening torque that the fastening screw can be turned further, follow the instructions at "Remounting the screw".
 - ① The prescribed tightening torques can be found in Chapter 9.2 "Specifications for mounting onto a machine", table "Tbl-11".

Remounting the screw

	<ul style="list-style-type: none"> • Make sure that it is possible to remount the screw on the gearhead without damaging the entire machine.
--	---

- Loosen the screw.
- Remove the glue residue from the threaded bore and the screw.
- De-grease the screw.
- Coat the screw with a threadlocker (e.g. Loctite® 243).
- Screw in the screw and tighten it with the prescribed tightening torque.

7.2 Startup after maintenance work

- Clean the outside of the gearhead.
- Attach all safety devices.
- Do a trial run before releasing the gearhead again for operation.

7.3 Maintenance schedule

Maintenance work	At startup	First time after 500 operating hours or 3 months	Every 3 months	Yearly
Visual inspection	X	X	X	
Checking the tightening torques	X	X		X

Tbl-6: Maintenance schedule

7.4 Notes on the lubricant used



All gearheads are lubricated for their service life by the manufacturer with a mineral oil-based lithium soap grease or with a food-safe synthetic grease (carbon hydride oil, aluminum complex soap) (see identification plate). All bearings are permanently lubricated by the company.

The manufacturer listed below will provide any further information on the lubricants:

Standard lubricants	Lubricants for the food industry (USDA-H1 registered)
Castrol Industrie GmbH, Mönchengladbach Tel.: + 49 2161 909-30 www.castrol.com	Klüber Lubrication München KG, Munich Tel.: + 49 89 7876-0 www.klueber.com



Tbl-7: Lubricant manufacturers

7.5 Disposal

Consult our Customer Service department for supplementary information on exchanging the adapter plate, on disassembly, and on disposal of the gearhead.

- Dispose of the gearhead at the recycling sites intended for this purpose.
 - ① Observe the locally valid regulations for disposals.

8 Malfunctions


	<p style="text-align: center;">NOTICE</p> <p>Changed operational behavior can be an indication of existing damage to the gearhead or cause damage to the gearhead.</p> <ul style="list-style-type: none"> Do not put the gearhead back into operation until the cause of the malfunction has been rectified.
	<p>Rectifying of malfunctions may only be done by specially trained technicians.</p>

Fault	Possible cause	Solution
Increased operating temperature	The gearhead is not suited for the task.	Check the technical specifications.
	Motor is heating the gearhead.	Check the wiring of the motor.
		Ensure adequate cooling.
		Change the motor.
Increased noises during operation	Ambient temperature too high.	Ensure adequate cooling.
	Distortion in motor mounting	Please consult our Customer Service Department.
	Damaged bearings	
Loss of lubricant	Damaged gear teeth	Please consult our Customer Service Department.
	Lubricant quantity too high	
	Seals not tight	Please consult our Customer Service Department.

Tbl-8: Malfunctions

9 Appendix

9.1 Specifications for mounting onto a motor

		Designation
	H	Clamping bolt
	I	Clamping ring (part of the clamping hub)
	J	Bushing
	K	Motorshaft

Tbl-9: Arrangement of motor shaft, clamping hub, and bushing

Clamping hub interior Ø [mm]	Code letter	Clamping screw (H)/ DIN ISO 4762	Width across flats [mm]	Tightening torque [Nm] property class 12.9	max. axial force clamping hub [N]
8	Z	M3	2.5	2	70
9	A	M3	2.5	2	70
11	B	M4	3	4.1	70
14	C	M5	4	9.5	70
16	D	M6	5	14	150
19	E	M6	5	14	150
24	G	M8	6	35	220
28	H	M6	5	14	220
32	I	M10	8	79	300
38	K	M10	8	79	300

Tbl-10: Specifications for mounting onto a motor

9.2 Specifications for mounting onto a machine

Gearhead size NP / NPL	Hole circle Ø [mm]	Bolt size / Property class	Tightening torque [Nm]
005	44	M4 / 12.9	4.55
015	62	M5 / 12.9	9.0
025	80	M6 / 12.9	15.4
035	108	M8 / 12.9	37.5
045	140	M10 / 12.9	73.5

Tbl-11: Specifications for mounting onto a machine

9.3 Tightening torques for common thread sizes in general mechanical engineering

The specified tightening torques for headless screws and nuts are calculated values and are based on the following conditions:

- Calculation in accordance with VDI 2230 (February 2003 version)
- Friction value for thread and contact surfaces $\mu=0.10$
- Exploitation of the yield stress 90%
- Torque tools type II classes A and D in accordance with ISO 6789

The settings are values rounded to usual commercial scale gradations or setting possibilities.

- Set these values **precisely** on the scale.

	Tightening torque [Nm] with thread												
Property class Screw / nut	M3	M4	M5	M6	M8	M10	M12	M14	M16	M18	M20	M22	M24
8.8 / 8	1.15	2.64	5.2	9.0	21.5	42.5	73.5	118	180	258	362	495	625
10.9 / 10	1.68	3.88	7.6	13.2	32.0	62.5	108	173	264	368	520	700	890
12.9 / 12	1.97	4.55	9.0	15.4	37.5	73.5	126	202	310	430	605	820	1040

Tbl-12: Tightening torques for headless screws and nuts



WITTENSTEIN alpha GmbH · Walter-Wittenstein-Straße 1 · 97999 Igersheim · Germany
Tel. +49 7931 493-12900 · info@wittenstein.de

WITTENSTEIN - one with the future

www.wittenstein-alpha.de